



NoSpray® Shields are designed to contain the spray of hazardous liquids in vessel engine rooms, a cause of dangerous fires and loss of life and property.

NoSpray® Shields are manufactured in multiple layers from a silicone rubber applied on a silica fibre fabric, specially formulated to withstand high temperatures and pressures, and an aluminum foil lining, which creates a corrosion resistant barrier for long lasting protection.

NoSpray® Shields are available in various widths which can be cut to size for use on flanges, valves, fittings, or any irregular shaped surface which can leak hazardous liquids. NoSpray® Shields encapsulate the protected surface and are easily installed using our drawstring system. Removable, reusable and extremely durable, NoSpray® Shields provide a consistent, clean look in vessel engine rooms.



## MEETS SOLAS REGULATION II -2 / 15.2.11



WIDTH	LENGTH	ROLLS/BOX
100 mm (4")	5 m (16.5')	3
150 mm (6")	5 m (16.5')	2
300 mm (12")	5 m (16.5')	1

4" Roll for typical flanges on a 25 mm (0.5") to 50 mm (1") pipe diameter

6" Roll for typical flanges on a 50 mm (1") to 100 mm (2") pipe diameter

12" Roll for typical flanges on a 100 mm (2") pipe diameter and up

### Installation Instructions

- 1 Measure the outside diameter of the flange and cut the NoSpray Shield to a length of 130%.
- 2 Cut a small hole about 1" (25mm) from each end of the shield on the pocket.
- 3 Centre the shield on the flange and wrap snugly, overlapping the ends.
- 4 Thread a lacing wire through each of the two cut holes and pull the lacing wire through the pockets.
- 5 Draw together and fold under the cut edge of Shield for a neat finish.
- 6 When pulled together snugly, secure with pliers and cut off excess wire.

### Assembly Cutaway

